



1. Motor plate
MP-9 Sofftail
MP- 11 FXR/FLT
MP -12 Dyna 1990-2000
MP-122 Dyna 2001-Up
MP-10 Shovelhead 1970-78
2. Starter housing
SH-9 Sofftail,FXR,Dyna
SH-10 Shovelhead
3. Side Guards
SP-9 Sofftail, Dyna
SP-11 FXR
SP-10 Shovelhead
4. Standoffs (set of 4)
5. 5/16-18 x 1 1/4 (set of 2)
6. 5/16-18 x 2 1/2 (set of 4)
7. 5/16-18 x 1 1/2 (set of 4)
8. 5/16-18 x 3/4 Button head cap screw (set of 4)
9. PG-100 Pinion gear (Sofftail,FXR, Dyna)
PG-200 Pinion gear (Shovelhead)
10. 1/4 -20 x 2 1/2 Socket head screw 1990-94 Starters
10-32 x2 1/2 Socket head screws for 1994-up starters
1/4-20 x 1 1/2 Socket head screws for PG-200

11. MPB-9 Motorplate bearing
Sofftail ,FXR,Dyna
MPB-10 Motorplate bearing Shovelhe
12. CC-193 C-clip (#193 Internal clip ring)
13. AC-100 Alternator cover 1986-up only
14. 1/4-20 Buttonhead screws (set of 3)
15. Pulley Covers Front & Rear
MD-100 Sofftail,FXR,Dyna
MD-200 Shovelhead